

Rechts
(right)

Anlegepunkt Abschlepphakenabdeckung
(Point of application cover towing hook)

Schablone für den Heckschürzenausschnitt für BMW 5er F10/F11 M-Paket (Template for the tail apron cutout for BMW 5Series F10/F11 M-package)

Designkante
(design edge)

Designkante
(design edge)

Beschneittkante
2xØ90mm
(cutting edge 2xØ90mm)

Beschneittkante
2xØ84mm
(cutting edge 2xØ84mm)

